

## NOTES

1. FOR USE ONLY WHEN RESTRAINT IN ACCORDANCE WITH W-11 IS DEEMED TO BE NON-APPLICABLE.

- 2. FITTING FLANGE BOLTS SHALL REMAIN FREE OF CONCRETE.
- 3. DO NOT BACKFILL UNTIL CONCRETE HAS SET FOR A MINIMUM OF 4 HOURS.
- 4. PIPELINE SHALL NOT BE CHARGED OR TESTED UNTIL CONCRETE HAS ACHIEVED FULL STRENGTH.
- 5. SEE G-4B FOR "b" VALUES FOR THRUST BLOCKS.
- 6. REDUCE "b" DIMENSION IN SOLID ROCK AS APPROVED BY ENGINEER.
- 7. EXPOSED BOLTS, STRAPS, AND NUTS SHALL BE PAINTED WITH APPROVED BITUMASTIC PAINT.
- 8. PLACE TWO LAYERS OF 15 LB. BUILDERS FELT BETWEEN FITTING/BOLTS AND CONCRETE AND BETWEEN STAINLESS STEEL STRAPS AND PIPE FITTING.

## **PROFILE**

## AUGUSTA COUNTY SERVICE AUTHORITY VERONA, VIRGINIA

SCALE: NTS

DRAWN BY: ACSA

DATE: AUG. 2004

REVISED: MAR. 2021

TYPICAL THRUST BLOCK DETAIL VERTICAL CREST ANCHORS

DRAWING NUMBER: G-4A

PAGE: 1 OF 2

2b